

# **Procion MX Dyes** ICE DYEING

## **PROCION MX DYES**

PROCION DYES are suitable for dyeing COTTON, SILK & WOOL. They give bright clear colours and can all be mixed to extend the colour palette.

These dyes belong to the 'Reactive' class of dyes and rely on their natural affinity for the fibre as well as the

chemical reaction caused by changing the PH of the dye with Alkali [Soda Ash). This gives them very good light and wash

Ice Dyeing Method is great for amazing patterning and uses Soda presoak fabric. Ice Cubes and undissolved dve powder. As the ice melts, the dye dissolves and starts to dye the fabric. If you use the mixture shades of the dyes they split into different colour components. If you use pure colours you'll get variations of the same colour. \*\* Check our list of Pure Procions – the rest of the colours are mixtures.

#### PREPARING THE FABRIC | GARMENT

Wash well in hot soapy water to remove any sizing, grease or dirt. Presoak the fabric/garment in Soda Ash see 'PRESOAK'

Dye - Choose a few colours : a little goes a long way so begin with 1/4 teaspoon of each. Using salt shakers is a clever way to sprinkle the dye or you can use a teaspoon. Wear your dust mask while you do this.

Soda Ash – \*\*20 gms [4 teaspoons] per litre soaking bath **Dynazol Wash Off** 

2mls per litre of rinsing bath

## INSTRUCTIONS - PRESOAK

- Using hot water, make up a Soda presoak bath. Soak your fabric / garment for at least 20 mins so its completely saturated.
- Remove from bath and squeeze out any excess solution back into the presoak [this can be kept for future use] Use the spin cycle on your washing machine for large amounts.

#### **INSTRUCTIONS** –

- Squeeze out excess Soda solution from and use the fabric while it is still wet
- Sit wire rack in drainage tub
- Scrunch, fold or pleat the fabric and arrange it on wire
- Cover the entire fabric surface with ice cubes.
- Sprinkle dye powder on the ice then cover with plastic and let it sit for 24 hours . As the ice dissolves the colours blend and dve the fabric.
- After 24 hours RINSE WELL first in cold water with Dynazol, then HOT soapy water. Using Dynazol in your first rinse will help remove unfixed dye and save water.

## **EQUIPMENT**









Measuring Spoons



Wire Rack







**Drainage Tub** 

Ice Cubes

Kraftkolour, Unit 2/99 Heyington Ave, Thomastown, Victoria, Australia, 3074 Ph: 61 3 9465 4865 Web: Kraftkolour.net.au Email: info@kraftkolour.com.au